



# COMPETITION HOOD & DECK PIN KIT WITH LANYARD CABLES #1616

## Installation Instructions

1. Determine stud location on hood or deck. Mark location, center punch and drill 1/2" diameter hole.
2. Place stud into 1/2" hole, mark location on radiator support. Lift hood, center punch and drill 7/16" hole through radiator support.
3. Install stud into radiator support by threading 7/16"-20 hex nut onto stud, insert stud into hole and thread second 7/16"-20 hex nut onto stud.
4. Adjust stud height so the horizontal hole allows washer and safety pin to be installed (refer to illustration).
5. Depending on style, locate and install chrome washer by removing backing paper for self-adhesive type, or drill four (4) 3/32" holes and screw chrome plate onto top of hood. Install safety hood pin. It may be necessary to re-adjust stud height.
6. Attach one end of lanyard cable to safety pin and other end to bolt or nut on radiator support to secure cable.
7. Open and close hood to be sure there is no interference. Hood should be seated flush with fenders in closed position. Install safety pins.
8. Replacement scuff plates, lanyard cables and safety clips are available from Prestolite Performance.

